

INSTRUCTIONS



Disassembly of Flooring with the Clic Connect Glueless Installation System

- 1) Before the disassembly of the floor, remove the skirtings and transition mouldings around perimeter and in doorways.
- 2) When disassembling hardwood, veneer, laminate and cork flooring equipped with a glueless installation system, you need to start with the last row that was installed.
- 3) You can see which row was installed last from the board width in this row, which is usually smaller than the width of the boards in the other rows. Another characteristic is that laying is generally started with a complete board. Hence, the last board has most often been cut to size and is thus shorter than the other boards. Start the disassembly at this side.
- 4) Disassembling must be carried out row by row and very carefully in order to avoid damage to the surface finish. First, release the whole board row by repeatedly lifting and lowering (rattling) the boards slightly while pulling each board at the long side which faces the wall.
- 5) When the complete board row has been released, you can release the boards of the row one after the other at the short sides by slightly lifting the endmost board.
- 6) The disassembly must always be performed extremely carefully to avoid damage to the locking mechanism. Only then will the product reinstall faultlessly.
- 7) The disassembled boards then need to be protected from moisture and damage. Only properly packed products can be transported without damage and can be reinstalled.